


# FITTING INSTRUCTIONS


## EUL LEVER ON BACKPLATE




**1.** Mark out centre hole **A** depending on the backset of your lock/latch. Using a 35mm diameter bit, drill centre hole **A** to a depth of 10mm on both sides of the door.

Then using a 20mm diameter bit, drill centre hole **A** through the door.


**Note:** This product is only suitable for doors with a minimum depth of 44mm.




**2.** Insert the spindle into the lever and securely fix the grub screw, ensure enough spindle is free to pass through the door and to be secured in the opposing lever.




**3.** Offer the lever up to the door so the spindle passes through centre hole **A** for the latch/lock and mark the fixing holes **B** using the screw holes on the back plate as a guide.




**4.** Offer the second lever up to the opposite side of the door and use the marking method outlined in step 3.




**5.** Remove the levers from the door. Using a 2mm diameter bit, drill pilot holes to a depth of 5mm.



**6.** Offer the levers back to the door and insert the screws. Using a screwdriver fix the levers to the door using the predrilled pilot holes.



**7.** Once secured to the door, tighten the remaining grub screw and recheck all fixings are secure. If the levers do not operate freely, check alignment of all components.



### Maintenance

For care instructions and technical information, please visit our website.